



NOTE - INSTALLATION OF PANEL ASSEMBLY -  
REMOVE ALL FINISH, INCLUDING ANODIZING FILM, BETWEEN  
SUPPORT, CLIPS AND PANEL. CLEAN WITH CAREFUL  
TETRAHYDROFUR AT ASSEMBLY. AS QUICKLY THEREAFTER  
AS POSSIBLE, APPLY FINISH AROUND JOINT.

NOTE -  
ALL PARTS USED ON ALL ASSEMBLIES  
EXCEPT AS NOTED